



SINGLE OUTLET MANIFOLD ASSY

FOR PB-I STYLE PLUG-INS

Specifications

Part Number: 4110-401- ()

Dimensions: (A) Height: See Table

(B) Length: See Table*

(C) Weight: See Table*

(D) Style: See Table

(E) Outlet Port Outside Dia: 0.75

**Note: Based on Using 45 Degree Fitting.*

Description: Single place PB-1 Type outlet in aluminum block (square or contoured). Square blocks include two mount holes with 10-32 threads for mounting. Manifolds include 2 nylon spacer washers, an oxygen warning placard and a threaded spanner washer.

Manifold Assy will accept couplings from Aerox P/N 4110-605-1 and 4110-609, Avox P/N 802039, 802627, BE Aerospace P/N 118041, 173017, 173701, 173703, ZF750.

Maintenance: 5 Year Overhaul
(Recommended)
Service Life Indefinite.



Part Number	A (Height)	B (Length)	C (Weight)	D (Style)
4110-401-1	1.65"	3.9" (Max)	4.7 OZ	1" X 1.25" Through
4110-401-2	1.65"	2.68" (Max)	3.5 OZ	1" X 1.25" Plugged
4110-401-3	1.5"	3.8" (Max)	3.8 OZ	Contoured Through
4110-401-4	1.5"	2.65" (Max)	3.5 OZ	Contoured Plugged