



PUSH/PULL CABLE

Specifications

Part Number: 4110-495

Dimensions:

Length: 108.0 inches

Weight: 0.4 Lbs

Thread: 3/8"-24

Max Pull Distance: 2 Inches

Description: Push/Pull Cable consist of galvanization steel flex housing with a polyethylene sleeve inside the housing to provide glide free movement, a stainless steel solid wire, a 6061-T6 aluminum knob that is painted green, and a label. A 6061-T6 sleeve and zinc plated nut is installed at one end of the cable to allow for panel mounting.

Push/Pull Cable come in nine (9) foot length.

Maintenance:

Push/Pull Cable: On-Condition

Operating Temp. Range: -65° F To 160° F
(-54° C To 70° C)

